

## 4x4 Front Hitch Installation

### Contents:

- 1 – Front Hitch
- 4 – U-bolts (5/16 x 1 3/8)
- 8 – 5/16" Nylock nuts
- 8 – 5/16" flat washers

### Tools required:

½" wrench

1. Place the hitch between the two vertical front frame rails.
2. Insert U-bolts and install a washer and nut on each end.
3. Tighten nuts evenly so that the same amount of threads show on each side.

