



## Chuck Wagon Soft Cab Enclosure

### Notes:

- Requires Brister's folding windshield accessory (not included).
- Soft cab can be used with or without ABS hard top.
- Holes must be punched in soft cab to use hard top.
- Doors will close on outside of hard top or the hard top can be trimmed to clear the doors. (Brister's recommends closing the doors on the outside of the top.)

Fastener package includes:

4-clamps

8-7/16 nuts & bolts

left and right doors

4-hinge clamps

A-back Bar

2-D bars

\*\*\* Remove ABS Hard top and windshield before installation\*\*\*

1. Install clamps around middle of the upper rear bends of cage, secure back bar (A) to clamps with 7/16 nuts and bolts.



2. Assemble door by inserting middle bar (D) into one side of door and tap with rubber mallet. To match up door halves, the hinge pin should be on the outside of the rear half while the long latch handle is on the inside of the front half. Insert crimped ends into opposite side of door and tap together. Repeat for second door.



3. Install door hinge clamps on rear cage bar next to top of seat and below bottom of seat. Secure with 7/16 nuts & bolts. Insert hinge pin into hinge clamp (long handle will be on inside of door.)



4. Adjust door by moving clamps to desired area. Tighten nuts & bolts. Follow same procedure for opposite door.



5. Slide skin over cage and secure Velcro around framing. Remove door framing and fasten Velcro onto framing.



7. To re-install windshield, punch holes into fabric to align with holes into cage. Insert the windshield screws from the back (nuts on outside). Position top flap to determine where Velcro will be attached to the under side of the top lip or windshield. Cut & attach Velcro. Secure top flap to windshield with Velcro.



8. A flap is provided to seal bottom of windshield. Position flap to determine where self adhesive Velcro will be attached. Cut Velcro to size and apply across hood and lower windshield. Secure flap.



9. If you plan to install the optional ABS plastic hard top, you will need to punch holes into fabric to align with clamps and re-secure with mounting hardware. Brister's recommends closing the doors on the outside of the top. Or, you can trim the top to clear the doors if you prefer:

- A. Remove the black edge trim from the top.
- B. Protect the sides of the top with masking tape.
- C. Trace around the door with a pencil on the tape.
- D. Remove the top and cut along line with a jig saw.
- E. Re-install top and edge trim.



Shown with optional back cap (not included)