

Table of Contents

Section 1	Introduction	pages 4-5
	Your Vehicle's Model, VIN and Serial Number	5
Section 2	Safety	pages 6-12
	Warning Labels / Safe Operating Procedures	7-9
	Electric / Hybrid Vehicle Specific Warnings & Cautions	10
	Before You Drive	11-12
Section 3	Assembly Instructions	pages 13-16
Section 4	Inspection	page 17
Section 5	Operation	pages 18-24
	Responsible Operation and Rider Safety	18-20
	Replacement Parts, Accessories and Service	21
	2WD and 4WD Gas UTV Operating Instructions	22
	Electric UTV Operating Instructions	23
	Gas / Electric Hybrid UTV Operating Instructions	24
Section 6	Maintenance	pages 25-33
	General UTV Maintenance	25-29
	Headlight Adjustment / Replacement	30
	Electric / Hybrid UTV Specific Maintenance	31-33
Section 7	Troubleshooting	pages 34-35
Section 8	Wiring Diagrams	pages 36-42
	Honda / Subaru / Briggs & Stratton Wiring Diagrams	36-38
	48V Wiring Diagrams / Hybrid Wiring Diagrams / Terminal Block Wiring	39-42
Section 9	Warranty	pages 43-45
	Full Size UTV Warranty Statement	43
	Service and Warranty Contact Information	44
	UTV Setup and Pre-Delivery Checklist	45
Pre Drive Inspection Checklist		Back Cover



7625 DiSalle Boulevard
Fort Wayne IN 46825

62194 Commercial Street
Roseland, LA 70456

Toll Free 800-643-7332
Fax 800-399-1399
www.amsportworks.com